



How to install an HB adapter in your regular phone?

Installing an HB adapter in your regular phone is very simple.

- 1 Connect the phone line to the space identified as Phone out in the HB adapter.
- 2 Connect the modular cable to the space identified as Phone in on the adapter.
- 3 Connect the RCA audio cable to the spot identified as audio in on the adapter.
- 4 Make a call to the phone system and place it on hold by pressing the adapter's Hold Button.
- 5 Then, adjust the volume with the volume control in our audio playback machine.
- 6 To come back to the call, pick up the phone and press the hold button.

