

How to install the BA 704-2 adapter?

Each BA 704-2 adapter comes with: 1 modular cable, 1 RCA audio cable, 1 line splitter.

- 1 Connect your phone's modular cable to the spot identified as phone in the adapter.
- 2 Then connect one end of the modular cable we sent you to the spot identified as Line 1 in the adapter. Install the opposite end to your phone.
- 3 If you have two phone numbers, connect the line splitter to the space identified as Line 1 in the adapter. Install one number to L1 and the other in L2.
- 4 Connect one end of the RCA audio cable to audio in on the adapter. Install the other end to our audio playback machine.
- 5 Connect the adapter to the power outlet 120 VAC, and you're done.

